



User Manual Hamburger Press

The Perfect Burger

3 in 1 Hamburger Press
Makes Regular, Stuffed or Mini Burgers



Large Base for regular or stuffed burger

Regular Burger

Fill the *large base* with burger mince and flatten it with the *large base*. Push up the base plate from below to release the burger.



Small Base for mini burger/slider

Stuffed Burger

Partially fill the *large base* with burger mince and flatten it a little bit with the *large press*. Then use the *indent press* to create a well (release the *indent press* from the *large base* by twisting the handle while holding the base). Add your favorite fillings and place a final layer of burger mince on top. Use the *large press* to smooth and seal the burger.

Push up the base plate from below to release the burger.



Large press to seal and smooth regular or stuffed burger

Mini Burger / Slider

Fill the *small base* with burger mince and flatten with your palm. Push up the *base plate* from below to release the burger.



Indent press to create a well for fillings (detachable from large press above)

Care Instructions

Dishwasher Safe
Dry thoroughly before storing